

Corner Desk + Corner Leg

1. Install side legs and tighten with M10 Washers and Bolts.
2. Install Corner Leg, align to cutout location at the tube and tighten with the corner leg.

