

Metal Modesty Panel

1. Adjust the depth location.
2. Screw the adapters to Modesty Panel.
3. Secure the adapter to the desk understructure.

