



# Think Headrest Assembly Instructions

Tool : T-15 Driver



Insert the steel bar into a gap between frame and back cushion.



Coordinate with holes of headrest and holes of steel bar.



There are four screw holes.



Drive a screw in tightly with T-15 driver.