


Organization Rail



1. Remove the Organization Rail Cap.



Organization Rail


2. Loosen the Pressure Plate from the Orgarail Adapter.

3. Position the Connector Plate to face outward of the Organization Rail. Slide in the Pressure Plate and the Orgarail Adapter to the first slot of the Organization Rail.



Organization Rail


4. Secure Orgarail Adapter to Pressure Plate at 190mm from the Organization Rail edge and fit in back the Organization Rail Cap.
5. Repeat step 1 to 4 to install the Orgarail Adapter on the other end of the Organization Rail.



Organization Rail + Under Structure

6. Slide out the table tops.

7. Place the Organization Rail in between the Under Structure Connectors.



Organization Rail + Under Structure

8. Place the Clamp Plate and tighten the M8 bolts.
Repeat this step to the rest of the connectors.

9. Slide in the table tops.

Clamp Plate

