


media:scape

Digital wiring & Switcher Configuration
Câblage digital & Configuration Switcher
Digital Verkabelung & Switcher Konfiguration







1 Column - 1 Colonne - 1 Säule




Digital wiring
Câblage digital
Digital Verkabelung





01 Puck connexion





02 Switcher power connexion






Power cable provided with the table
Câble d'alimentation fourni avec la table
Netzkabel im Lieferumfang des
Tisches enthalten




Switcher transformer



03 Bezel to switcher connexion




To switcher
CTRL port









04 Scaler


Plastic zipper









Scaler:
placed on the back of the totem
Placé à l'arrière du totem
Hinter dem Totem festmachen



05 Scaler output HDMI to screen connexion



06 SCALER Output HDMI to screen connexion




PUCK

PUCK


PUCK

PUCK

PUCK




07 Switcher output HDMI to SCALER connexion





Installation


Bezel




Scaler





HDMI câble



Switcher



Switcher transformer



PUCK

PUCK

PUCK

PUCK

PUCK


PUCK

2 Columns- 2 Colonne- 2 Säulen




Digital wiring
Câblage digital
Digital Verkabelung




00 Cabling




01 Puck cable extension




02 Coupler






03 Puck cable connexion




04 Puck connexion




05 Y cable to switcher connexion




06 First Bezel to switcher connexion




07 Bezel extension cable connexion




08 Second Bezel to switcher connexion




Installation 2 columns




Switcher configuration
Configuration switcher
Switcher Konfiguration





01 Configuration of media:scape switcher








02 Configuration of media:scape switcher





03 Navigation media:scape switcher





04 Configuration media:scape switcher




05 Switcher configuration Number of Screen



06 Switcher configuration Number of Screen



07 Switcher Standby configuration (in minutes)



08 Save configuration of media:scape switcher

