



1



Remove the upper unit from the box. Hand holes are in the cartoning to assist in removal from the box.
NOTE: This is a two person job.
从包装盒中取出上部单元。盒子的手洞可协助上部单元从盒子里拿出来。
注：这是两个人的工作。




2







3




4







9




10




11




12




- 13** Add mounting brackets to back of monitor.
安装支架在显示器后面




Slots are provided in brackets to accommodate monitors where the holes do not align with monitor mounting pattern.
金属支架里的插槽可供其它牌子的电视机



40" Monitor



42" Monitor



Do not exceed maximum monitor weight and maximum diagonal size of 42".
NOTE: The monitor weight for a media:scape mobile is rated up to a maximum of 55 pounds (25kg).
不要超过最大的显示器的重量。注：media:scape mobile 显示器重量被评为最高到55磅(25 公斤)。

Replace monitor power cord 更换显示器的电源线

14a

Remove power cord supplied with monitor and replace with power cord provided.

CAUTION: Maximum monitor current not to exceed 5 amps.

NOTE: Steps shown represent 42" LG monitor application only.

取出电视机的电源线，然后将它更换于提供的电源线

注意：目前最大使用显示器不超过5安培

注：应用42"LG显示器来代表所示步骤


42" LG Monitor

Replace the
existing power
cord

with

the one
provided by
Steelcase


把电视机的电源线更
换于提供的电源线



14b

Plug the power, monitor connection and audio from the media:scape Mobile to the monitor.


把 media:scape Mobile 的电源 · 显示器连接和音频 插到显示器




15

Install monitor onto media:scape Mobile.


安装显示器到 media:scape Mobile.



Monitor security locking features



Kensington Lock



Padlock

To remove monitor, locate anti-dislodgement clips on each side. Press them towards the monitor, lift monitor up & out.

要去除显示器 · 找出每边的反夹子 · 把它按往显示器 · 解除显示器。

16



Install shroud onto media:scape Mobile.

NOTE: During assembly, listen for two (2) “clicks” to ensure that the shroud anti-dislodgement clips fully engage with shroud “L” bracket.

注：在安装时

注：在装配过程中，听(2) “点击”。

以确保覆盖反移位剪辑充分从事覆盖的“L”支架





To remove shroud, locate anti-dislodgement clips on each side. Press them towards the monitor and lift up & out.

要去除覆盖，找出每边的反夹子。把它按往显示器，解除显示器。



OPTIONAL 可选

Install camera shelf onto media:scape Mobile.
安装网络摄像在media:scape Mobile




OPTIONAL 可选


Install video conferencing shelf onto media:scape Mobile.
安装视频会议在media:scape Mobile

1a**1b**


2a



2b



3



4

