


⚠ CAUTION: TIP OVER HAZARD

Do not install Coat Hanger on Stools with plastic bases



If you have a problem, question, or request, call
your local dealer, or Steelcase Line 1 at
888.STEELCASE (888.783.3522)
for immediate action by people who want to help you.

(Outside the U.S.A., Canada, Mexico, Puerto Rico,
and the U.S. Virgin Islands, call: 1.616.247.2500)
Or visit our website: www.steelcase.com

© 2015 Steelcase Inc.
Grand Rapids, MI 49501
U.S.A.

Printed in U.S.A.

⚠ CAUTION: TIP OVER HAZARD

Do not install Coat Hanger on Stools with plastic bases


1. Install LH and RH metal clips with tabs facing away from back of chair. One (1) tab at each side of chair. Slide clips down to rest on small bumps.

NOTE: Clips are handed. Indent in clip should face down and align with bump.

2. Center the coat hanger on top of the chair with the front edge of the coat hanger over the plastic edge on the top of the chair back.

3. Rotate the coat hanger backward and press the side wall hooks up to clip under each side, you should hear a small 'click' noise (3a). At the bottom of the mount, push inwards with a high force (3b). You will hear a distinct 'snap' when the tabs (installed in step 1) have clipped into the mount.

4. Visually check to verify the coat hanger is engaged. Gently pull coat hanger forward and back to confirm it is secured to the chair back.



Indent facing down

1

INDENT IN
METAL CLIP
BUMP

SEE NOTE

(LH clip shown)

4

3b

MOUNT

3a

SIDE WALL
HOOK