


height adjustable lumbar Place hands on left and right sides to glide up or down.



## seat depth


Lift lever and hold, slide seat forward or back, and release lever to lock.



#### back tension


Controls resistance to body weight.

Turn knob forward for more resistance and backward for less.



### seat height adjustment

To raise the chair, lift your body weight and pull lever up. To lower the chair, stay seated and pull lever up.



### back stop

4 comfort settings

Set recline angle by rotating the paddle to any of the four positions. When the paddle is horizontal, the back will allow you to fully recline.





### 3-way adjustable arm rests

(forward/back, side-to-side, up and down)

Press button to adjust arms.



height adjustable lumbar

Place hands on left and right sides to glide up or down.



## seat depth

Lift lever and hold, slide seat forward or back, and release lever to lock.



### seat height adjustment

To raise the chair, lift your body weight and pull lever up. To lower the chair, stay seated and pull lever up.



## back tension

Controls resistance to body weight.

Turn knob clockwise for more resistance and counterclockwise for less



# back lock

Position locking mechanism

Set lock by pushing down the paddle.

