Steelcase®

Required Tools

6 mm

1. Allen Key

16mm

2. Spanner

3. 2 persons are needed

September 2008

Steelcase®

FRAME ONE BENCH
Assembly Instruction - Exploded View for Frame One Bench Extension

Required Tools

6 mm

1. Allen Key

16mm

2. Spanner

3. 2 persons are needed

September 2008

Basic Single Structure Desk

1. Screw the beams to the end frame, 15Nm.

**2. Screw the beams to the second end frame, 15Nm.**

September 2008

Basic Single Structure Desk

3. **Slot the sliding desk top glide onto the beams.**

4. Slot the sliding tops into the sliding desk top glide.

## Basic Single Structure Desk

5. **Fix the sliding tops in place to do this, undo the clamp protection.**

6. **Close the sliding top lock.**

7. **Screw the sliding top runners to the clamping plate, 5Nm.**

September 2008

Steelcase®

Basic Single Structure Desk + Extension

**8. Screw the beams to the end frame, 15Nm.**

9. Screw the beams to the supporting legs, 15Nm.

September 2008

Basic Single Structure Desk + Extension

**10. Screw the beams to the second end frame, 15Nm.**

11. Slot the sliding desk top glide onto the beams.

September 2008

Steelcase®

Basic Single Structure Desk + Extension

12. **Slot the sliding tops into the sliding desk top glide.**

13. **Fix the sliding tops in place to do this, undo the clamp protection.**

⑬

⑫

September 2008

Basic Single Structure Desk + Extension

14. Close the sliding top lock.

15. Screw the sliding desk top glide to the clamping plate, 5Nm.

September 2008