Assembly Directions


Installation of a Table - Standing Height Montage d'une table-Hauteur position debout Montage eines Tisches - Stehhöhe




Summary - Sommaire - Zusammenfassung

• Appendix - Annexe - Zubehör

Steelcase










Steelcase

TOOLS / OUTILS / WERKZEUG



















































































































Steelcase
























































Steelcase













Steelcase







Top and Bezel installation Montage Plateau et Bezel Montage Tischplatte und Technikklappe
































Wiring Câblage Verkabelung


Refer to assembly directions for wiring C00133_1 Se référer à la notice de montage du câblage C00133_1 Siehe Installationsanleitung für die Verkabelung C00133_1





media:scape Hotline + 33 (0) 3 88 13 36 36



Pyramid Cover Installation Capot Pyramid Pyramid Bezug Montage








APPENDIX - ANNEXE - ANHANG





PUCK Cable replacement Remplacement câbles PUCK PUCK Kabelersatz



















Model: PDM110THN PANEL DISPLAY MOUNT

Thank you for purchasing the PDR panel display mount.

To insure the correct usage, please read and follow the instruction manual throughly. Please store the instructions in a safe place for future reference.

All PDR mounts and adapters carry a limited lifetime warranty from ship date against defects in material and workmanship. We are not liable for improper installation that results in damage to mounts, adapters or presentation equipment.

Special techniques are necessary for installation of the panel display mount.

- Do not attempt to perform this work by yourself.
- Request an installation specialist to install this unit.
- Manufacturer assumes absolutely no responsibility for injuries and damages that may occur due to improper installation and handling.
- Please remember that if you remove the panel display from the wall later, you will find the screw holes and anchor bolts for the mounting unit left on the wall. Aso note that long use of the panel display may discolor the wall around it due to its heat and

To ensure customer safety, be sure to decide the installation location so that the strength is sufficient to withstand the weight of both the panel display and the wall mount.


Always use at least two persons for all installations.

Fully tighten all of the mounting screws as specified in the installation instructions.


Parts Configuration Chart Display bracket 2 pcs

В

Model # 110 = 20"









G 0 6 mm x 16 mm Phillip screws...4 pcs 6mm x 40mm Philips screws...4pcs


8mm x 16mm Philip screw...4 pcs

Square multi-mount washers...4 pcs use with F,G,H,Lor M mounting screws 8mm x 40mm Philip screws...4 pcs Plastic spacer...4 pcs

Features

- Low profile 15/16" (23.7mm)
- 16" or 24" stud mounting points
- Easy installation
- 1 1/2" & 3" vertical height adjustment
- Lateral movement from center for better viewing position.

Mounting points for panel display models



INSTALLATION LOCATION



0

The wall where the wall mount is to be installed must be capable of long-term support of the total load of the panel display and wall mount. Measures should also be taken to ensure sufficient strength to withstand the force of earthquakes, vibration and other external forces.

Note: Incorrect installation can cause the panel display to fall and cause injury.

Total load of the panel (panel display + wall mount)

MAXIMUM WEIGHT - 200 LBS (92 kg.)

INSTALLATION ON A WOODEN WALL

Always install so that the load is supported by a wood stud. If the strength of the wood studs is not sufficient, add reinforcement.

Do not install on decorative posts or plaster board.

Always confirm the center of the stud is used for the installation.



CAUTION

- Avoid installing in locations where the temperature and humidity are excessively high, and where contact with any
 water is possible. These can result in fire or electric shock.
- Do not install close to an air conditioner intake or outlet. Do not install in locations where there are excessive amounts of dust, oily smoke or tobacco smoke. Fire could result.
- Do not block the ventilation holes. Leave sufficient clearance in regard to the surroundings to avoid blocking the ventilation.
 The internal temperature could elevate and possibly result in fire. Install the panel (4") or more away from surroundings.
- Install only on a vertical surface. Avoid sloped surfaces. Also, do not install facing upward. The internal temperature could
 elevate and possibly result in fire. Injury or damage could also result from falling.
- Do not install in locations where there is excessive vibration or impact. Injury and damage could result from the panel display falling.
- Do not install where there is direct sunlight or other strong light. Strong light could result in eye fatigue during usage.



- Use the specified bolts and screws in the specified places and tighten firmly. Failure to do this could cause injury if the panel display falls.
- Do not alter any of the parts. Do not use broken parts. This could result with injury due to the panel display falling.
- Make sure that both hooks from each pivot bracket engage with the wall bracket. Failure to do so could cause the panel display
 to fall.
- Always use at least two people to perform the installation work. Injury could result from dropping heavy objects.

Caution: Installation of unit is to be carried out by qualified technicians only. Install in an appropriate location by checking the wall structure and durability for safety and accident prevention.

Rev 092007

2




1. FASTEN MOUNTING PLATE TO WALL

The bracket must be secured to the center of the wall studs capable of holding at least four times the weight of the unit. Use a stud finder to determine the stud center line of the wall stud.

The wall bracket should be mounted at the same horizontal center line as the display center line.

Pre drill 3/16" (5 mm) holes for the lag bolts Fig 2.

With the flange facing up on the wall plate. See Fig 3 Use the four lag bolts (e) and washers supplied (d) level and secure the mounting plate to the center of the wall studs.



2. SECURE THE DISPLAY BRACKETS TO THE MONITOR


Place the display panel face down on a protected surface.

Position the bracket (A) with the slots facing towards the top See Fig 4

Using the proper screws and the square multi-mount washers supplied (F,G,H,J,or K and I)

Position the brackets equal distance from the bottom and top ,tighten hardware.

NOTE: In some applications the plastic spacer (L) and longer screws (J or K) may be required to add clearance for the back panel. Do not over tighten hardware, damage to the display may result.



3


3. MOUNT THE DISPLAY TO THE WALL MOUNT BRACKET


Lift the display with the brackets A attached, onto the wall plate. See Fig 5 Position the hooks on bracket A to the wall plate B, using the desired height adjustment slot. See Fig 5 & 6
Insert the locking bar (C) as shown in Fig 5 (B).

Make sure the display brackets engage the rails on the wall mount bracket (B) See Fig 6.

Slide the locking bar thru the bracket (A) slots. If security is desired place a lock (not supplied) thru the hole in the locking bar. Fig 6









4. Adjust lateral movement

Lateral Movement:

Once the installation of the display on the wall is complete you can still move the display left to right to optimize the final viewing position, by gently sliding the unit on the wall bracket. The adjustment distance will vary depending on the display model being installed. Fig 7







Steelcase

