



Empath™

user guide

The Empath recliner is designed to reduce stress and the potential for injury for both patients and clinicians while increasing physical and emotional connectedness.




CENTRAL LOCK



Press pedal to lock casters. Press down again to unlock. *(standard feature)*

FOOTREST LEVER




Rotate to open and close the footrest separately from reclining. *(standard feature)*

ARM GRIP/ FOOTREST SCALLOP




Grip front of arms and tuck feet into scallop to help enter or exit. *(standard feature)*

BACK RECLINE PADDLE




Squeeze paddle up to recline and return to upright. *(standard feature)*

FLIP-DOWN ARM



Pull release strap to unlatch, then gently rotate arm down.

FLIP-UP TABLET ARM



Push button on tablet arm then gently rotate tablet down. Pull to raise; swivel as desired.

TRENDELENBURG

Using red pedal (located on both sides of chair), tilt patient's head below feet.


- 1 Fully extend footrest.
- 2 Fully recline back.
- 3 Depress and hold Trendelenburg pedal to release mechanism.
- 4 Press seat back downward then release pedal to achieve Trendelenburg position.



Empath™

user guide

The Empath recliner is a crucial step forward in the patient care process – one developed entirely from real-world insights.




HEADREST



Move up or down to adjust. Flip over back of chair if not needed.

PULL-OUT FOOTREST




Slide out for elevated foot surface.

PUSH BAR




Grip bar on top or sides to easily maneuver the chair.

DIRECTIONAL STEERING




Press pedal to engage directional casters. Press down again to disengage.

DRAINAGE BAG HANGER




Insert hook from drainage bag through metal ring of hanger.

IV POLE AND HOLDER



Fit pole into holder. Use thumb screw to adjust height.

HEAT/MASSAGE



Push buttons – heat on right, massage on left – to cycle three settings of each function.