

3480 Windquest Dr. Holland, MI 49424 PH 616-928-0791 FAX 616-928-0792 www.furnituretest.com



Page 1 of 5

Requester:	Orangebox US Inc.	
	3445 East Paris Ave SE	
	Grand Rapids, MI 49512	
Contact Name / Number:	Russ Whitaker (616) 285-2545 x10	
Dates Tested:	07/20/15 to 07/28/15	
Date Submitted:	07/30/15	
Technician:	Ron Day	
Customer Request I.D.	N/A	

Scope: To evaluate the AD-33DC, manufactured by Orangebox US Inc., by subjecting it to the following tests:

Requested Tests:

Test Name	Requirement
Backrest Strength Test – Horizontal – Static	ANSI/BIFMA X5.4-2012, Section 5
Backrest Durability Test – Horizontal – Cyclic	ANSI/BIFMA X5.4-2012, Section 7
Unit Drop Test - Dynamic	ANSI/BIFMA X5.4-2012, Section 17
Stability Tests	ANSI/BIFMA X5.4-2012, Section 21

Product Description:

Specimen	Description	<u>Supplier</u>
1	AD-33DC - 120° Seat, Internal Back & Screen	Orangebox US Inc.

Summary:

Test Name	Results
Backrest Strength Test – Horizontal – Static	Passed
Backrest Durability Test – Horizontal – Cyclic	Passed
Unit Drop Test - Dynamic	Passed
Stability Tests	Passed

This report shall not be reproduced, except in full, without written permission from Advanced Furniture Testing, Inc. Results contained within this report only apply to the actual product tested under the testing conditions documented in this report.



3480 Windquest Dr. Holland, MI 49424 PH 616-928-0791 FAX 616-928-0792 www.furnituretest.com



Page 2 of 5


Test Results:

1. Backrest Strength Test – Horizontal – Static:

Testing was performed per ANSI/BIFMA X5.4-2012, Section 5.

Notes:

- Temperature / humidity 74° F / 56 RH%.
- Load applied 16" up from the seat at the side to side center of each seating position on the backrest.
- See Photo 1 for setup.



<u>Specimen</u>	Load	<u>Time</u>	<u>Observations</u>
	<u>(lbs.)</u>	(sec.)	
1	150 x 2	60	No loss of serviceability.
	250 x 2	60	No sudden and major change in structural integrity.

Requirement:

<u>Functional Load:</u> A functional load applied once shall cause no loss of serviceability to the unit.

<u>Proof Load:</u> A proof load applied once shall cause no sudden and major change in the structural integrity of the unit. Loss of serviceability is acceptable.

Equipment:	Test machine (TM-029), CMD (TD-046), Tape measure (TD-094),
	Digital protractor (TD-059), Stopwatch (TD-010)



3480 Windquest Dr. Holland, MI 49424 PH 616-928-0791 FAX 616-928-0792 www.furnituretest.com



Page 3 of 5

2. Backrest Durability Test – Horizontal – Cyclic:

Testing was performed per ANSI/BIFMA X5.4-2012, Section 7.

Notes:

- Temperature / humidity 73 76° F / 53 58 RH%.
- Load applied 16" up from the seat at the side to side center of each seating position.
- Test rate: 26 cpm.
- See Photo 2 for setup.



Specimen	Cycles	<u>Observations</u>
1	0	Test begun - Position 1.
	120,000	No loss of serviceability.
	120,000	Test resumed - Position 2.
	240,000	No loss of serviceability.

Requirement: There shall be no loss of serviceability.

Equipment:	Test machine (TM-029.2), CMD (TD-046), Tape measure (TD-094),
	Digital protractor (TD-059), Stopwatch (TD-010).



3480 Windquest Dr. Holland, MI 49424 PH 616-928-0791 FAX 616-928-0792 www.furnituretest.com



Page 4 of 5

3. Unit Drop Test – Dynamic:

Testing was performed per ANSI/BIFMA X5.4-2012, Section 17.

Notes:

- Temperature / humidity 74° F / 55 RH%.
- Unit weight: 130 lbs.
- Each end of the unit was raised 4.7" and allowed to free-fall to the floor.
- See Photo 3 for setup.



<u>Specimen</u>	End	<u>Observations</u>
1	Left Side	No loss of serviceability.
	Right Side	No loss of serviceability.

Requirement:

There shall be no loss of serviceability.

Equipment:	Tape measure (TD-094), Scale (TD-008)



3480 Windquest Dr. Holland, MI 49424 PH 616-928-0791 FAX 616-928-0792 www.furnituretest.com




Page 5 of 5

4. Stability Tests:

Testing was performed per ANSI/BIFMA X5.4-2012, Section 21.

Notes:

- Temperature / humidity 74° F / 55 RH%.
- Unit weight: 130 lbs.
- Front stability load applied at a 45° downward angle at the front edge of the seat surface.
- Minimum rear stability force calculation: 1.1(47-18) = 31.9 lbs.
- Minimum front stability force calculation: $130 \times .40 = 52 \text{ lbs}$.
- See Photo 4 for rear stability setup, and photo 5 for front stability setup.



Specimen	Stability	<u>Force</u>	Observations
1	Rear	83.0 lbs.	The unit did not tip over.
	Front	52.1 lbs.	The unit did not tip over.

Requirement:

Rear Stability: Application of the force shall not cause the unit to tip over.

Front Stability: The force shall not be less than 40% of the total unit weight.

Equipment:	Digital Level (TD-073), Tape measure (TD-094), Scale (TD-008),
	Force Gage (TD-007)

Reviewed by: Dan Kolean – Lab Manager Approved by: Dan Kolean – Lab Manager Version 1.0